



Glove box for IE for sodium methyllate



- Improve the handling of dangerous chemicals by a glove box.
- The adding of the catalyst into the reactor can be dosed by the pneumatic lift system.
- Any self-ignition is protected by the steel tank and the nitrogen purge.
- The entire bags (double sealed) will be put into the glove box just be eyeglasses and mouth filter. The opening is done from outside by the gloves and under vacuum.
- The design in steel and glass insure, that it is tight also in a failure situation, when chemical starts catching fire. The safety equipment with the temperature transmitter and the nitrogen purge improve the safety in failure situation.
- Locker system allows smooth feeding automatically.